



# GROWATT – DYNESS LI-ION BATTERY

## PRODUCTS

### 1 x GROWATT INVERTER



### 1 x DYNESS LI-ION



## NOTES

## CONNECTIONS

**BEFORE SWITCHING THE BATTERY ON MAKE SURE THAT:**

1. THE COMMUNICATION CABLE IS BEING USED (CAN CABLE).
2. COMMUNICATION CABLE IS INSERTED IN 'CAN IN' ON BATTERY AND 'CAN/BMS' ON INVERTER.
3. DIP SWITCHES ARE 0010 (ONLY 3 UP).

## SETTINGS

### **STEP 1**

SWITCH ON THE 'ON/OFF' BREAKER ON THE BATTERY.  
THEN PRESS AND HOLD THE 'SW' BUTTON FOR '3-5 SECONDS'.  
THE BATTERY LIGHTS SHOULD SWITCH ON AND BATTERY WILL GIVE OUT POWER.

### **STEP 2**

SWITCH ON THE INVERTER VIA THE POWER SWITCH.  
THE DISPLAY SCREEN WILL SWITCH ON AND YOU WILL HEAR A BEEP.

### **STEP 3**

PRESS AND HOLD THE 'ENTER' BUTTON TO GO TO 'SETTINGS'.  
PRESS THE 'UP/DOWN' BUTTONS TO SCROLL TO 'SETTING 005'.  
PRESS 'ENTER' TO SELECT 'BATTERY TYPE'  
SCROLL 'UP/DOWN' TO 'LI (LITHIUM)'.

### **STEP 4**

PRESS 'ENTER' TO GO TO 'PROTOCOL SETTINGS 036'.  
SCROLL 'UP/DOWN' TO SELECT 'PROTOCOL L52'.  
THEN PRESS 'ENTER' THEN 'ESC' BUTTON.

### **STEP 5**

ALLOW THE BATTERY AND INVERTER TO SYNC.

