



GROWATT – FREEDOM E TOWER

PRODUCTS

1 x GROWATT INVERTER



1 x DYNESS LI-ION



CONNECTIONS

BEFORE SWITCHING THE BATTERY ON MAKE SURE THAT:

1. THE COMMUNICATION CABLE IS BEING USED (TYPE 1 CANBUS).
2. COMMUNICATION CABLE IS INSERTED IN 'CAN' ON BATTERY AND 'CAN' ON INVERTER.
3. DIP SWITCHES ARE 1000 (ONLY 1 UP).

SETTINGS

STEP 1

SWITCH ON THE 'ON/OFF' BREAKER ON THE BATTERY.
THEN PRESS AND HOLD THE 'RST' BUTTON FOR '3-5 SECONDS'.
THE BATTERY LIGHTS SHOULD COME ON AND BATTERY WILL GIVE OUT POWER.

STEP 2

SWITCH ON THE INVERTER ON THE POWER SWITCH.
THE DISPLAY SCREEN SWITCHES ON AND YOU WILL HEAR A BEEP.

STEP 3

PRESS AND HOLD THE 'ENTER' BUTTON TO GO TO 'SETTINGS'.
PRESS THE 'UP/DOWN' BUTTONS TO SCROLL TO 'SETTING 005'.
PRESS 'ENTER' TO SELECT BATTERY TYPE
SCROLL 'UP/DOWN' TO 'LI (LITHIUM)'.

STEP 4

PRESS 'ENTER' TO GO TO 'PROTOCOL SETTINGS 036'.
SCROLL 'UP/DOWN' TO SELECT 'PROTOCOL L52'.
THEN PRESS THE 'ESC' BUTTON.

STEP 5

ALLOW THE BATTERY AND INVERTER TO SYNC.

NOTES

